


BRANTZ CANBUS Wiring Kit

BR47

This option is for attaching the CANBUS Sensor directly to a Brantz Meter with no Plug.

- Connect the BR47 to the BR56/BR57/BR58 – Connect to corresponding crimped ends as colour coded:
 - RED – RED
 - BLUE – BLUE
 - YELLOW – YELLOW
 - GREEN – GREEN
- Connect the other end of the BR47 to the Black and Grey Cables coming from the Tripmeter as follows:



BR47 Wiring Kit → Grey Sensor Cable from Meter	BR47 Wiring Kit → Black Power Cable from Meter
BLUE Spade → BLUE Core	BROWN terminal block → BROWN Core
YELLOW Spade → BROWN Core	GREEN/YELLOW terminal block → GREEN/YELLOW Core
GREEN/YELLOW Spade → GREEN/YELLOW Core	

BRANTZ
Rallymeters

Right Track Enterprises Ltd

www.brantz.co.uk

v1.0

BRANTZ CANBUS Wiring Kit

BR47

This option is for attaching the CANBUS Sensor directly to a Brantz Meter with no Plug.

- Connect the BR47 to the BR56/BR57/BR58 – Connect to corresponding crimped ends as colour coded:
 - RED – RED
 - BLUE – BLUE
 - YELLOW – YELLOW
 - GREEN – GREEN
- Connect the other end of the BR47 to the Black and Grey Cables coming from the Tripmeter as follows:



BR47 Wiring Kit → Grey Sensor Cable from Meter	BR47 Wiring Kit → Black Power Cable from Meter
BLUE Spade → BLUE Core	BROWN terminal block → BROWN Core
YELLOW Spade → BROWN Core	GREEN/YELLOW terminal block → GREEN/YELLOW Core
GREEN/YELLOW Spade → GREEN/YELLOW Core	

BRANTZ
Rallymeters

Right Track Enterprises Ltd

www.brantz.co.uk

v1.0